


CHEMLINE WP WAFER CHECK VALVE

INSTALLATION AND MAINTENANCE INSTRUCTIONS For Chemline 2" - 12" Wafer Check Valves

Installation

- 1. The WP Wafer Check Valves are designed to fit between flat face flanges.
- 2. Low torque flange gaskets are required for PP wafer check valves. PVC wafer check valves contain a body O-Ring seal and do not require low torque flange gaskets.
- 3. Centre by means of body rim (external) diameter.
- 4. Assemble between DIN/ANSI flanges. Use soft gaskets and tighten.
- 5. Flange bolts should be well lubricated. With plastic flanges it is important to use washers.
- 6. Utilization of other flanges (i.e. DIN 2512/12/14), threaded. flared or slip-on flanges require a disc stem locking device.
- 7. Tighten bolts with a torque wrench evenly and in symmetrical pattern as shown below.



- 8. The following should be observed when assembling on to the discharge side of the pump:
 - (a) Never assemble directly on to pump flange.
 - (b) Never assemble on to a bend or elbow.
 - (c) Allow an additional distance of 5 10 times the nominal width before installing the wafer check valve.





CHEMLINE

Installation & Maintenance Wafer Check Valves cont.

- 9. Distance pieces are required when polypropylene check valves are fitted in plastic pipe systems.
- 10. The recommended torques are tabled below:

Valve Size	Bolt Torque (ft-lb)	
	PVC	PP
2"	20-30	12.3
2-1/2"	20-30	14.5
3"	20-30	14.5
4"	20-30	14.5
5"	-	18.1
6'	33-50	18.1
8"	33-50	21.7
10"	53-75	25.4
12"	80-100	29.0

MAINTENANCE

Refer to **DRAWING WC1 rev 0.** And proceed as follows:

- 1. Remove spring (6) by putting tension on lower portion and pushing upward.
- 2. Loosen screws (5) and remove disc (4).
- 3. Inspect disc and O-rings (3) for wear and replace if necessary.
- 4. Inspect body O-rings (2) for wear and replace if necessary.
- 5. To re-assemble valve repeat steps 4 through 1 in reverse. Do not over tighten screws (5).



